

 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O
 O

 Important SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS


 Important SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS


 Important Safety Information of the state of t



BEACON WALL MOUNT[™] (BWM)

Round Canopy Instructions







Additional Info

- Please follow National and Local electrical codes for your area.
- Suitable for through wire.
- Suitable for installation into combustible materials.
- Rated for 90° C.
- Junction box, universal mounting ring screws, box mounting hardware and gaskets (By Others)
- $\underline{\wedge}$ Junction box must be secured to a structural member suitable for weight of the luminaire and other weight likely to be placed upon it.
- Install junction box (By Others) so that front face is flush with finished ceiling. Seal connections (See wiring diagram). building envelope as per NEC.


Phase 2 - Fixture Installation



Remove fixture body from stem by loosening 1. two (2) #8-32 set screws with a 5/64" Allen wrench. Disconnect quick disconnect from leads to fixture body.




Loosen locking ring set screw using a 5/64" Allen 2. wrench. Slide locking ring and canopy cover forward on stem to expose mounting plate.




WIRING DIAGRAM

- 3. Connect primary branch circuit wiring to fixture leads using watertight wire connectors (By Others) as per NEC. Connect green fixture wire to green supply wire. See wiring diagram.
- 120V only.



Place wiring and connections into junction box. 5. 4. Mount plate with mounting hardware (By Others) to junction box. Seal building envelope as per NEC. Do not overtighten.


TEKAILLUMINATION



Reconnect quick disconnects. Slide fixture body onto stem, then tighten two (2) #8-32 set screws with a 5/64" Allen wrench.

40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900

www.tekaillumination.com • info@tekaillumination.com



Slide locking ring and canopy cover back until mounting plate is covered. Tighten set screw on 6. locking ring using a 5/64" Allen wrench.


IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS



DATE

5-4-18

REFERENCE NUMBER
INS-2574-00



THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF TEKA ILLUMINATION AND ITS RECEIPT OR POSSESSION DOES NOT CONVEY ANY RIGHTS TO REPRODUCE, DISCLOSE ITS CONTENTS, OR TO MANUFACTURE, USE OR SELL ANYTHING IT MAY DESCRIBE. REPRODUCTION, DISCLOSURE OR USE WITHOUT SPECIFIC WRITTEN AUTHORIZATION OF TEKA ILLUMINATION IS STRICTLY FORBIDDEN.

TEKAILLUMINATION

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS

40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900

www.tekaillumination.com • info@tekaillumination.com

RELEASE DATE

5-4-18

REFERENCE NUMBER


INS-2574-01



BEACON WALL MOUNT™ (BWM)

Rectangular Canopy Instructions

Phase 1 - Rough In




Additional Info

- Please follow National and Local electrical codes for your area.
 - Suitable for through wire.
- Suitable for installation into combustible materials.
- Rated for 90° C.
- Junction box, universal mounting ring screws, box mounting hardware and gaskets (By Others)
- \bigwedge Junction box must be secured to a structural member suitable for weight of the luminaire and other weight likely to be placed upon it.


Install junction box (By Others) so that front 3. Connect box to conduit and pull wires for face is flush with finished ceiling. Seal to building envelope as per NEC.

connections (See wiring diagram).


Phase 2 - Fixture Installation



Remove fixture body from stem by loosening two (2) #8-32 set screws with a 5/64" Allen wrench. 1. Disconnect quick disconnect from leads to fixture body.




Loosen locking ring set screw using a 5/64" Allen 2. wrench. Slide locking ring and canopy cover forward on stem to expose mounting plate.




WIRING DIAGRAM


3. Connect primary branch circuit wiring to fixture leads using waterproof wire connectors (By Others). Connect green incoming ground wire to green ground wire on plate. See wiring diagram.



4. Place wiring and connections into junction box. Mount plate with mounting hardware (By Others) to junction box. Seal building envelope as per NEC. Do not overtighten.



Reconnect quick disconnects. Slide fixture body 5. onto stem, then tighten two (2) #8-32 set screws with a 5/64" Allen wrench.



Slide locking ring and canopy cover back until 6. mounting plate is covered. Tighten set screw on locking ring using a 5/64" Allen wrench.

IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS



DATE

5-4-18

REFERENCE NUMBER
INS-2574-01

TEKAILLUMINATION


40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.tekaillumination.com • info@tekaillumination.com




IMPORTANT - WEAR GLOVES TO AVOID GETTING FINGERPRINTS ON THIS PRODUCT. MANY TEKA ILLUMINATION PRODUCTS ARE DESIGNED TO NATURALLY PATINA. OILS FROM YOUR SKIN WILL ACCELERATE THIS PROCESS WHERE TOUCHED AND ARE NEARLY IMPOSSIBLE TO REMOVE. THIS PROCESS OCCURS OVER TIME AND IS DETERMINED BY THE INSTALLATION ENVIRONMENT.

IMPORTANT SAFETY


- Product must be installed by a qualified person in a manner consistent with its intended use and in compliance with the National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes.
- Follow product label information and instructions.
- Qualified Personnel must perform all servicing or relamping of this product.
- Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker before service.




1. Remove lower assembly of fixture to access LED board. Loosen set screws with 7/64" Allen wrench.




2. Gently press on tabs of LED wire holders to allow wiring to be removed from LED board.



 Loosen LED board from heatsink by using 5/64" Allen wrench on three (3) #2-56 screws on LED board.




4. Remove old board by carefully pulling away.




 Spread new thermal paste in even layer on heatsink. Feed wiring from quick connect through new board.

Line up new LED board and place on heatsink.




6. Secure new LED board to heatsink with three (3) #2-56 screws using 5/64" Allen wrench.

TEKAILLUMINATION



 Connect wiring to new LED board by placing into wire connectors. Wire will 'push' into place inside holder. Black wire inserts on AC Line, while white wire inserts on Neutral.

> 40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.tekaillumination.com • info@tekaillumination.com



8. Reverse install fixture body assembly by tightening set screws with 7/64" Allen wrench.

IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS



DATE

7-18-18

REFERENCE NUMBER INS-2614-00